


AC6 - PPPoE (以中華電信為例)


確認線路，來源網路與 WAN 連接，電腦與 LAN 連接



開啟瀏覽器 (網頁)，在網址輸入：192.168.0.1 或 tendawifi.com
點選「開始體驗」



機器自動檢測您的網路連線類型為 PPPoE



Tenda WiFi

192.168.0.1/index.html

請選擇您的連線方式

經檢測，推薦您的連線方式為：**PPPoE(ADSL撥號)**

選擇連線方式：

ADSL帳號：

ADSL密碼：

[下一步](#)

[跳過此步驟](#)

輸入申請之電信業者所發配的使用者名稱及密碼，此以中華電信為例，輸入完畢後點下一步



Tenda WiFi

192.168.0.1/index.html

請選擇您的連線方式

經檢測，推薦您的連線方式為：**PPPoE(ADSL撥號)**

選擇連線方式：

ADSL帳號：

ADSL密碼：

[下一步](#)

[跳過此步驟](#)

輸入申請之電信業者所發配的使用者名稱及密碼，此以中華電信為例使用者名稱為8個數字@hinet.net

設定無線網路帳號(可更改)及密碼、路由器管理員密碼(可與無線密碼相同或不同；亦可不設定密碼，可自行勾選)，輸入完畢後點下一步



The screenshot shows the Tenda WiFi configuration interface in a browser window. The address bar shows '192.168.0.1/index.html'. The page title is 'Tenda WiFi'. The main heading is '無線設定' (Wireless Settings). There are three input fields with labels and checkboxes:

- Field 1: 'Tenda_F64590' with a Wi-Fi icon. Label: '可更改無線網路名稱' (Can change wireless network name).
- Field 2: '請設定8~32位數無線密碼' (Please set 8~32 digit wireless password). Label: '設定無線網路密碼' (Set wireless network password). A checkbox '無須密碼' (No password) is next to it.
- Field 3: '請設定5~32位數的登入密碼' (Please set 5~32 digit login password). Label: '路由器的登入密碼' (Router login password). A checkbox '無須密碼' (No password) is next to it.

There is also a checkbox: '將無線密碼同時設為路由器管理員密碼' (Set wireless password as router administrator password).

At the bottom, there is an orange button labeled '下一步' (Next Step).

設定成功，請點選「更多功能」



The screenshot shows the Tenda WiFi configuration interface after successful setup. The address bar shows '192.168.0.1/index.html'. The page title is 'Tenda WiFi'. The main heading is 'Tenda'. The page displays a success message:

恭喜您，可以上網了!
請連線無線訊號
AC6
或 AC6_5G

您還可以限制連線設備的網速，設定WiFi定時開關

At the bottom, there is an orange button labeled '更多功能....' (More Functions....).

確認網路狀態為已連線，就可以上網囉！

The screenshot displays the Tenda WiFi management interface in a browser window. The address bar shows the URL `192.168.0.1/main.html`. The page title is "網路狀態" (Network Status). On the left, there is a navigation menu with the following items: 網路狀態 (Network Status), 連線設定 (Connection Settings), 無線設定 (Wireless Settings), 來賓網路 (Guest Network), 智慧省電 (Smart Power Saving), VPN設定 (VPN Settings), 進階功能 (Advanced Features), and 系統設定 (System Settings). The main content area shows a network diagram with three main components: "網際網路" (Internet) represented by a globe icon, "無線設定" (Wireless Settings) represented by a Wi-Fi icon, and "連線設定" (Connection Settings) represented by a green circle with a white checkmark. A green line connects the Internet and Wireless Settings components to the Connection Settings component. Above the Connection Settings component, there is a status indicator: "1 台設備在線上 | 黑名單 0" (1 device online | Blacklist 0). Below the Connection Settings component, a red dashed box contains the text "已連線，您可以上網了" (Connected, you can go online). To the right of the Wireless Settings component, there is a list of network settings: "2.4G網路：AC6" and "5G網路：AC6_5G". The interface also includes a language dropdown menu set to "繁體中文" and a "退出" (Logout) button.